

WAX HEATER RHH004

Model: RHH004

Certificate No.: XK2402013030C

TECHNICAL DATA:

Power: 40W

Nominal input: 220V

Nominal output: 220V

Capacity: 100 ml


Temperature: 140°C

1. SAFETY OF USE:

1. Before use, read the user manual carefully.
2. Keep the power cord away from the hot surface.
3. Do not drop the device or throw it into water, this may damage the wax heater.
4. Remember that the actual voltage used must correspond to the device parameters.
5. Do not use the device in a damp/wet environment. Otherwise, the device may stop working and/or be damaged.
6. When using the appliance, do not wrap the cord around the heater.
7. Do not epilate on sensitive, damaged or otherwise problematic skin.
8. After the end of use of the device, unplug them from the power supply network.
9. Clean the device after disconnecting it from the power supply.
10. To clean the device, use a soft fabric moistened with a wax-dissolving liquid. Do not clean or soak the device with water.
11. Please note that making self-switches and changes to your device is prohibited and equivalent to the loss of warranty. The manufacturer does not take responsibility for the correct and safe operation of the device.
12. **Keep away from children.**


2. SPECIFICATIONS DEVICE:

1. Power cable input socket
2. Window for wax quantity control
3. Hole for placing wax in roll



3. HOW TO USE:

1. Before use, make sure your skin is completely clean.
2. Place wax in device.
3. Plug the heater into the power supply and turn on the device.
4. Heat the wax for about 20-30 min.
5. Spread the product in the direction of hair growth, apply the wax once to an area of approximately 15-18 cm - if it is too warm, wait until it cools down or apply the wax to depilatory strips
6. Apply a depilatory strip onto the previously applied wax. Press it down with your hand.
7. Tear off the depilation strip against the direction of hair growth.
8. After depilation, remove any wax residue with a post-depilation product.
9. Apply a moisturizer to cleansed skin.
10. After the treatment, disconnect the wax heater from the power supply.



4. DIRECTIONS:

1. Clean the device when it is disconnected from power.
2. Do not depilate sensitive, damaged or other skin problems.
3. Do not expose the skin to the sun and UV rays for 24 hours after depilation.
4. To clean the device, use a soft fabric moistened with a wax-dissolving liquid. Do not clean or soak the device with water.



In accordance with *art. 13 sec. 1 of the Act of 11 September 2015 on used electrical and electronic equipment (Journal of Laws 2015 item 1688)*, we inform you about the correct handling of waste electrical and electronic equipment:

1. It is prohibited to place used electrical and electronic equipment together with other waste - this is confirmed by the marking in the form of a "crossed-out bin", which requires selective collection of this type of waste.
2. Electrical and electronic devices may contain hazardous substances, mixtures and components, which, after entering the environment, may pose a serious threat to the health and life of humans and living organisms.
3. Used electrical and electronic equipment should be transferred only to authorized collection points, the list of which should be included on the website of each Municipal Office.
4. Households play a key role in the waste management system for used electrical and electronic equipment due to the possibility of their direct transfer to authorized collection points and the elimination of undesirable social habits resulting in leaving waste equipment in places not intended for this purpose.

IMPORTER

GNBLAB sp. z o.o.
Piotrkowska 270
90-361 Łódź, Polska
uwagi@gnb-lab.com
gnb-lab.com

Made in PRC