

Nail Drill Molly Lac - POWERDRILL DM202

Technical parameters:

Model: DM202

Certificate No.: AT0517090055S, AT0517090055E

Maximum power: 65W

Turnover: 0-35000RPM

Power supply: rated input: 220V/ 50 Hz

Rated output: DC 12V



CAUTION:

The working tips tend to heat up at higher speeds. The amount of pressure you must apply requires practice. Speed selection depends on the cutter diameter. The larger the cutter or stone, the slower the speed should be set.

Installation:

For safety reasons, the milling machine must be disconnected from the mains supply when installing the pedal, handle or cutters. Connect the handle and pedal to the appropriate inputs of the milling machine. The cutters are inserted by turning the movable part of the handle to the left. After inserting the cutter, turn the movable part of the handle to the right. After attaching the tooling and cutters, the milling machine can be connected to the mains.

Conservation:

Metal, stone and diamond cutters can be sterilized in the sterilizer. Felt cutters and brushes should be cleaned with disinfectant fluid.

ADDITIONAL REMARKS:

- If the power cord is damaged, replace it with a new one of the same type at a service facility.
- It is forbidden to make any changes to the unit yourself.
- Opening the device is categorically prohibited and will void the warranty and the manufacturer assumes no responsibility for the proper and safe operation of the device.
- Keep away from children.
- Store and use in dry areas.
- The use of a dust extraction device is recommended; dust can cause damage to the milling machine

Preparation for work:

1. Press down gently but firmly on the desired tip
2. Set potentiometer to MIN position
3. Switch on the device in hand/manual or foot/pedal control position
4. Gradually adjust the speed according to the size and type of cutter or grinding wheel (Speed can be adjusted using the dial on the instrument or the foot pedal)

Nail drill bits:

A Nail drill bit consists of a shank and a cutting part, usually stone, metal, or diamond. The nail drill bit may have a grit.

Felts and brushes available.

CAUTION: Metal cutters cut only in the clockwise direction of rotation. For stones and diamonds the direction does not matter.

IMPORTER:

MollyLac, Michał Szewczyk
270 Piotrkowska
90-361 Łódź, Poland
mollylac.com
Made in P.R.C.

Warranty Card No......
 Model.....
 Price..... Date of sale.....

Terms of warranty:

1. A condition of accepting the device for repair is having a warranty card.
2. The warranty card without the device name, parameters and completed customer address fields is invalid.
3. The warranty is granted for a period of twelve months from the date of sale.
4. Defects revealed in this period will be removed free of charge within a period of no more than 28 business days from the date of delivery of the device at the customer's expense and sending the defective at the expense of the guarantor.
5. The warranty does not cover:
 - damage resulting from improper use, storage or maintenance of the device
 - mechanical, thermal, chemical and all other damages caused by intentional or negligent action of the user and due to external force
 - UV bulbs for the device
6. The Advertiser is required to provide equipment to the seller in the original factory packaging at his own expense. Damage caused by inadequate securing of shipping equipment is not subject to warranty repairs.
7. Loss of warranty:
 - in the event of arbitrary repairs by the user or other unauthorized persons
 - in the event of improper or inconsistent with the instructions for use, maintenance or storage
 - in the event of arbitrary alterations or structural changes
8. The buyer has the right to replace the equipment with a new one only in the event of a non-removable defect and in the event that during the warranty period 3 repairs are necessary and the equipment still exhibits defects preventing operation as intended.
 - cash back only after delivery of the purchase document
9. The equipment is intended for professional use only and in case of other use it loses the warranty.
10. The customer is obliged to describe the defect and existing defects and attach the description to the warranty card.

Customer's signature.....

Date of submission for repair	Date of repair	Repair Details	Employee's signature

Customer Data:

Name and surname.....
 Address.....
 Telephone number.....
 Goods advertised should be sent to:
 MollyLac, Michał Szewczyk
 270 Piotrkowska St.
 90-361 Łódź, Poland

Company stamp.....
 Date and signature of the seller