

# WAX WARMER YH-001 FOR CAN 100W - INSTRUCTION MANUAL



MODEL: YH001

certificate no: ST20170322101-LVD, ST20170323002-EMC

## Technical parameters:

- Power: 100W
- Voltage: 200-240 V 50-60 Hz
- suitable for 500ml cans

## WARNING:

1. do not use the appliance if:
  - It has a damaged power cord or plug.
  - Does not work properly.
  - Has been dropped/damaged.
  - Has been dropped into water.
2. Close supervision is necessary when children are near the appliance.
3. keep the power cord away from a hot surface.
- 4) Do not immerse the heater in water or other liquids.
- 5) Always use the equipment on a flat surface.
- 6) Unplug the power cord after use. Clean the unit after it has cooled down.
- 7) Do not wrap the cord around the heater during use.
- 8) Use the equipment exactly as described in the instruction manual.

## Method of use:

1. Remove the plastic cover.
2. Simply insert the wax can into the heater and connect the unit to the power supply.
3. Replace the lid, turn the temperature control knob and set to „HI“. Wait until the wax has reached a liquid consistency. This process takes approximately 15 minutes.
4. Turn the knob to the middle position („MED“) after the wax has reached a liquid consistency. The temperature will remain constant. It is important to check the temperature of the wax by placing a small amount on the inside of your wrist.
5. Remove the tin using the handle.
6. Switch off the heater by turning the knob counterclockwise („OFF“).
7. Wax heated to the optimum temperature applies evenly and does not drag or steam. The wax is applied with a wooden spatula, following the direction of hair growth. The strip is also glued in the same direction. The strip is then peeled off in the opposite direction (under the hair) with a vigorous movement against the skin. In order to avoid pain when peeling the strip off, the skin should be stretched slightly. Wax remnants are removed with a post-removal oil and then you can apply a hair growth retarding post-removal cream, which will make the hair softer and thinner and make subsequent epilation treatments easier.

## IMPORTER

GNBLab

Michał Szewczyk, Piotr Malinowski s.c.

Piotrkowska 270

90-361 Łódź, Polska

gnb-lab.com

Made in P.R.C.