

ALLELAC M17 NAIL DRILL MACHINE

Model: M17

Certificate No.: UNIA22011511SC-02



TECHNICAL SPECIFICATIONS:

Power: 68W

Rated input: 220V AC

Rated output: 12V 1.5A

Rotation speed: 45000 RPM

1. SAFETY INSTRUCTIONS:


1. Before first use, carefully read this instruction manual.
2. Ensure that the power supply voltage corresponds to the technical specifications of the nail drill.
3. Do not use the device in wet or humid environments or in conditions of high air humidity.
4. If the device is exposed to liquids, immediately disconnect it from the power supply. A flooded device must not be used again and should be sent to an authorized service center for inspection and possible repair.
5. Disconnect the device from the power supply if it will not be used for an extended period of time.
6. If the housing becomes dirty, clean it with a soft cloth slightly dampened with a mild detergent. Always clean the device only when it is switched off and unplugged.
7. Do not use acidic, abrasive, or aggressive cleaning agents.
8. Proper use and regular maintenance can significantly extend the service life of the nail drill.
9. In case of malfunction, contact a qualified service technician. Do not attempt to repair the device yourself.
10. Keep the device out of reach of children.

2. PACKAGE CONTENTS:

- nail drill base unit,
- handpiece,
- set of drill bits,
- foot pedal,
- user manual,
- handpiece holder,
- warranty card.

3. DEVICE DESCRIPTION:

1. Speed display (*×1000 RPM).
2. ON/OFF button – device power on/off and rotation direction control (R/F - forward/reverse).
3. HAND/FOOT button - selection of hand or foot control mode.
4. Speed control knob.
5. Handpiece.
6. Handpiece holder.
7. Power cable.



4. MAIN FEATURES:

The nail drill has been designed for professional manicure salons as well as for users performing nail styling at home. Its ergonomic design and comfortable handpiece ensure high working comfort, precision, and safe operation.

5. OPERATING INSTRUCTIONS:

1. Connect the power cable to a suitable power outlet.
2. Connect the handpiece to the appropriate socket on the device.
3. Press and hold the ON/OFF button to turn on the device. To change the rotation direction (forward/reverse – R/F), briefly press the direction switch button (as shown in the diagram).
4. Set the desired rotation speed using the speed control knob:
 - turning the knob to the right increases the speed (range 0–45,000 RPM),
 - turning the knob to the left decreases the speed.
5. The current rotation speed is displayed on the screen as a numeric value *1000.
6. Select HAND (manual control) or FOOT (foot pedal control) mode according to your preferred working method.
7. After finishing work, switch off the device and disconnect it from the power supply.

6. USE AND MAINTENANCE GUIDELINES:

1. Always connect the device only to a power outlet with voltage compliant with the technical specifications.
2. Keep the device out of reach of children.
3. Clean the device using a dry or slightly damp cloth with a mild detergent.
4. Protect the device from moisture.
5. Avoid prolonged exposure to direct sunlight to prevent overheating.
6. Do not change drill bits while the device is operating, as this may cause permanent damage to the handpiece.
7. If the device will not be used for a long period, unplug it and store it in a dry, well-ventilated place.



In accordance with art. 13 sec. 1 of the Act of 11 September 2015 on used electrical and electronic equipment (Journal of Laws 2015 item 1688), we inform you about the correct handling of waste electrical and electronic equipment:

1. It is prohibited to place used electrical and electronic equipment together with other waste - this is confirmed by the marking in the form of a "crossed-out bin", which requires selective collection of this type of waste.
2. Electrical and electronic devices may contain hazardous substances, mixtures and components, which, after entering the environment, may pose a serious threat to the health and life of humans and living organisms.
3. Used electrical and electronic equipment should be transferred only to authorized collection points, the list of which should be included on the website of each Municipal Office.
4. Households play a key role in the waste management system for used electrical and electronic equipment due to the possibility of their direct transfer to authorized collection points and the elimination of undesirable social habits resulting in leaving waste equipment in places not intended for this purpose.

IMPORTER
GNBLAB sp. z o.o.
ul. Piotrkowska 270
90-361 Łódź, Polska
hurt.gnb-lab.com
uwagi@gnb-lab.com

Produced for:
Allepaznokcie Michał Szewczyk
ul. Piotrkowska 270, Łódź
allepaznokcie.pl

Made in PRC